


Accessories

TM 24 Portable Printer™

Battery-operated Portable Printer



| TRAILMASTER | | | |
|---------------------------------|-----------------------|------------------------|-------------------|
| EVENT nbr 1 | TIME hh:nm 7:47 | DATE mo day 2 17 | FRAME nbr 1 |
| 3 | 7:47 8:24 8:25 | 2 18 | 2 |
| 5 6 - Thru | 7:35 16:32 | 2 19 | 3 4 |
| 2 3 4 5 6 - Thru | 8:25 7:35 | 2 19 | _ |

Printer Print-out

Portable
Prints data in list form
Uses standard 2 ¼" paper

The TM24 Portable Printer is a battery-operated, portable printer available for the TRAILMASTER trail monitoring system. The printer allows you to quickly retrieve accumulated data and take a hardcopy print-out with you. This accessory is not necessary for data retrieval, but it can be a time-saving device for those operators who frequently have to retrieve data from many units in the field, and do not have access to a computer. The TM24 Portable Printer requires a 12 volt power source, which does not come with the printer. 12 volt battery packs are available from Radio Shack or other local electronic supply house. Uses standard 2 1/4" roll of paper.